



VAPORBOOT PLUS INSTALLATION INSTRUCTIONS

Package Contents: 12 Each Preformed VaporBoot Plus Boots 18" x 18"



1. Check your pipe size and cut the hole size required in the prefabricated VaporBoot Plus Boot. The formed steps are for 1", 2", 3" and 4" PVC pipe or IPS size. This will allow the pipe to fit tightly in the hole and the VaporBoot Plus to stretch taunt around the pipe.
2. Turn the boot over and apply 2-sided Raven Butyl Seal tape (sold separately) to the perimeter of the bottom side. Once the entire perimeter is taped; remove all the release liner.
3. Force the VaporBoot Plus Boot over the penetration and apply pressure to the taped area around the entire perimeter to secure in place.
4. Peel off the paper release liner and tape the entire perimeter with VaporBond Plus tape (sold separately).
5. To finish boot installation take VaporBond Plus tape and wrap tightly around to seal the boot to the penetration.

